

SAMSUNG OFFICESERV CHANGE OF DSS BUTTON PROGRAMMING GUIDE

TO CHANGE THE EXTENSION NUMBER ALLOCATED TO A DIRECT
STATION SELECTION (DSS) BUTTON

From your handset press the **Transfer key** and dial **107**,

Press the **DSS button** you wish to change

The screen will show something like this

```
[204] EXT (MAST)
05:DS205 ->DS_
```

Enter the new extension number

**YOU CAN THEN SELECT A DIFFERENT BUTTON, ONCE YOU HAVE
FINISHED CHANGING THE BUTTONS PRESS THE TRANSFER KEY TO
SAVE & EXIT PROGRAMMING**

**NB: YOU CAN ONLY CHANGE THE EXTENDER OF A BUTTON THAT
HAS ALREADY BEEN SET UP AS A DSS KEY**



FOR MORE TECHNICAL TIPS PLEASE VISIT

WWW.PRPTTELECOM.CO.UK